



WORK INSTRUCTION W.I. EMS 1 V1

FATS DELIVERIES

Liquid RM spillages are a potential environmental pollutant. Care should be taken to minimise this risk and as such the following instructions are to be observed.

All deliveries are to be supervised by the Production Operative.

The Production Operative should check weighbridge documentation and:-

- Assess that there is space in the tank to accept the load by checking contents gauge
- Ensure that the driver has his own spill kit or knows the location of ours
- Check that the drip tray under the fill point is empty
- Instruct the driver to report any spillage immediately.
- Instruct driver to sample the load via bleed valve
- On completion any leaks/drips collected in tray or bucket must be disposed of as General Waste
- Ensure that signed delivery documentation is returned to the weighbridge
- In the event of a spillage the implement:-

Emergency Spill Procedure WI EMS 7

PLEASE DESTROY PREVIOUS COPIES

Signed:

Date: 20.01.2023

A handwritten signature in black ink, consisting of several loops and a long horizontal stroke at the end.

Copies to: Control Room & WI File