
The **ENVIROTANK** is an inner storage tank, externally encased within an outer weatherproof bund to ensure any leakage or nominal overfill situation is safely contained.

The **ENVIROTANK** is easily transportable as a one-piece unit and reduces costly and time consuming site work.

The **ENVIROTANK** is delivered by JA Envirotanks transport to the customers premises. If at a later date a new site for the **ENVIROTANK** is required it has only to be emptied of contents, cleaned internally, uplifted and transported to its new location.







## Envirotank Rectangular

Ref	Capacity Litres	Length mm	Width mm	Height mm	Weight (Approx) <b>Kg</b>
T30	2000	1180	1100	1830	865
T31	3000	1660	1180	1830	1027
T32	5000	2260	1460	1830	1531
T33	7000	2520	1790	1830	1940
T34	10000	3590	1790	1830	2540
T35	15000	4020	2398	1830	3395
T36	20000	5360	2398	1830	4285
T37	25000	6700	2398	1830	5162
T38	30000	6410	3008	1830	5828
T39	40000	8550	3008	1830	7474
T40	50000	10690	3008	1830	8947
T41	60000	10660	3618	1830	9707
T42	70000	12440	3618	1830	11790
T43	80000	14220	3618	1830	13316