Great Houndales Rearing Unit

Inspection and Maintenance Programme

Last Reviewed	 	

This programme details the areas of the Unit that need to be inspected and maintained on a monthly basis to help prevent any incidence of environmental damage or impact.

Monthly Inspection:

- Check all clean water drains are clear and running freely into soakaways
- Check the septic tank level and its discharge pipe. No dirty water should be flowing directly into the discharge pipe. If required arrange for it to be emptied.
- Check the dirty water pit level. If it is full arrange for it to be emptied. If you suspect it is leaking report immediately to management.
- Check internal and external of unit building to ensure it is weather and vermin proof.
 Report any damage to management immediately.
- Check all ventilation fans and chimneys are operating correctly and are unobstructed.
- Check areas of hardstanding are in good order. Pot holes should be repaired, along with any excessive cracking to concrete areas

When these checks have been complete the relevant box on the monthly stock count sheet should be initialled as confirmation.

Any Maintenance Issues Identified should be detailed in the Maintenance Issues and Resolution Log.